

Sunrise Instruments Calibration Report

Address: 2nd Floor Building B2 19#Keyuan Xishi Road Nanning Guangxi Province China 530007
Phone: +86 771-389-9499 Fax: +86 771-389-9497
Email: sri@srisensor.com



Calibration No.	SRI-OR-H002007	Cal Date	2025/11/27
Model No.	M4344A	Serial No.	26574
Technician	Wei Jing Xian	Temp(C)/Hum.(%).	20/50
Customer		Excitation(V)	5.00
Description	6 AXIS FORCE SENSOR	Cable Length	
Comments	搭配M8128C7 SN7836		

Voltage Calibration

<u>Bridge</u>	<u>Capacity</u>	<u>Zero Offset</u>	<u>Nonlinearity</u>	<u>Hysteresis</u>	<u>Output @ Capacity</u>	<u>Sensitivity</u>
	N/Nm	V	%FS	%FS	V	V/EU
FX	-400	-0.0272	0.05	0.11	-5.1222	1.2805E-02
FY	-400	-0.0252	0.06	0.08	-5.1039	1.2760E-02
FZ	-400	0.0503	0.03	0.08	-5.1440	1.2860E-02
MX	50	0.0088	0.03	0.06	5.1944	1.0389E-01
MY	-50	-0.2255	0.05	0.07	-5.2817	1.0563E-01
MZ	50	-0.0452	0.10	0.12	5.1760	1.0352E-01

Wire Color Codes

FUNCTION

+EXC

+SIG

-EXC

-SIG

Sensor ID

ID Return

CONNECTOR

Reference Load Cell

<u>Manufacturer</u>	<u>Model Type</u>	<u>Model No.</u>	<u>Serial No.</u>	<u>Cal Due Date</u>
SUNRISE	Golden Standard	SRI_2000N	123	2026.09.01
Traceable to the National Institute of Metrology China (NIMC)				

This calibration follows the calibration document SRI-LAB-BZ-001:2024 which defined in the Sunrise Instruments Lab

The load cell calibration system consists of a 300KN load frame CMT5305 made by SANS Testing Machine Co., Golden reference load cell by Interface. Data acquisition system by National Instruments.

Calibrated by

Approved by

Sunrise Instruments Calibration Report

Address: 2nd Floor Building B2 19#Keyuan Xishi Road Nanning Guangxi Province China 530007

Phone: +86 771-389-9499 Fax: +86 771-389-9497

Email: sri@srisensor.com



Calibration No.	SRi-OR-H002007	Cal Date	2025/11/27
Model No.	M4344A	Serial No.	26574
Technician	Wei Jing Xian	Temp(C)/Hum.(%).	20/50
Customer		Excitation(V)	5.00
Description	6 AXIS FORCE SENSOR	Cable Length	
Comments			

CROSSTALK

<u>Bridge</u>	<u>Load</u>	<u>FX</u>	<u>FY</u>	<u>FZ</u>	<u>MX</u>	<u>MY</u>	<u>MZ</u>
	N/Nm	% FS	% FS	% FS	% FS	% FS	% FS
FX	-400	0.00	0.24	0.17	0.28	0.28	0.36
FY	-400	0.30	0.00	0.09	0.38	0.03	0.28
FZ	-400	0.14	0.17	0.00	0.49	0.25	0.37
MX	50	0.87	1.90	1.34	0.00	0.41	0.25
MY	-50	2.04	1.31	0.06	0.38	0.00	1.13
MZ	50	0.09	0.32	0.18	0.22	0.22	0.00

Bridge to Transducer body resistance greater than 5G Ohm when measured with 50V excitation