



POSITIVE OUTPUT WHEN THE LOAD IS APPLIED TO THE UPPER PORTION PER COORDINATE SYSTEM

THE OUTPUTS ARE NOT STRUCTURALLY DECOUPLED
A 6X6 DECOUPLED MATRIX IS PROVIDED TO OBTAIN EACH COMPONENT

	Fx	Fy	Fz	Mx	My	Mz
CAPACITY (N/Nm)	20	20	40	1.5	1.5	1.0
OUTPUT (mV/V)	COUPLED					
BRIDGE RES. (Ω)	350	350	350	350	350	350

SPECIFICATIONS	
EXCITATION MAX. (V)	5
OVERLOAD CAPACITY (%F.S.)	250
CROSSTALK (%F.S.)	3.0
NON-LINEARITY (%F.S.)	1.0
HYSTERESIS (%F.S.)	1.0
OPERATING TEMP. RANGE (°C)	-40 TO +100
COMPENSATED TEMP. RANGE (°C)	10 TO 70
MASS (KG)	0.05

WIRING CODE - TWISTED PAIR

FUNC	CHN1	CHN2	CHN3	CHN4	CHN5	CHN6
+SIG	WHITE(BROWN)	ORG(BROWN)	BLUE(BROWN)	YEL(BROWN)	RED(BROWN)	WHITE(BLACK)
-SIG	BROWN(WHITE)	BROWN(ORG)	BROWN(BLUE)	BROWN(YEL)	BROWN(RED)	BLACK(WHITE)
+EXC	RED(BLACK)			BLACK(RED)		
-EXC	YELLOW(BLACK)			BLACK(YELLOW)		
"YEL"="YELLOW", "ORG"="ORANGE", "WHITE(BROWN)" = WHITE CABLE IN WHITE/BROWN PAIR						

SUNRISE INSTRUMENTS

www.srisensor.com

SIX AXIS SQUARE LOAD CELL, COUPLED
30X30X22MM, F20N

UNLESS OTHERWISE SPECIFIED
DIMENSIONS ARE IN MM

M4312G

REV.
0.1